

# 51758

## Installation instructions for S2211 SIP Phone modified for Arbour on Grey

1. Secure finalised HW1460 panel (51774) to wall using suitable M4 self tapping screws by at least 1 point top and bottom via the mounting holes denoted 'A' in drawing HW1460 rev 2.  
**Note:** Excess holes have been provided to accommodate for various mounting situations.
2. Connect the modified S2211 SIP phones (51758) keystone to the internal Cat 5 wall cabling as shown in Figure 1.
3. Attach the rear of the S2211 unit to the wall plate via the screws added to the panel during step 2.



Figure 2. Attaching Cat 5 network cable



Figure 3. Mounted S2211 SIP Phone