



## VSL-16xW INTERCOM STATION INSTALLATION DETAILS











- 1. RJ45 Concentrator connection is NOT Ethernet T568A Pinout. See documentation for correct termination.
- 2. Relay contacts rating: 30 V d.c. / 6 A
- Fit the intercom in place using M4x25 security screws & M4 nylon washers (supplied by Jacques, HW451, qty 6).
  Check gasket for presence of all 6 spacing washers sandwiched between panel and gasket at all fixing holes. These must be used. Without them, panel bowing will occur and may result in poor sealing.

©2018 Jacques Technologies PTY LTD

CHANGE DESCRIPTION MOUNTING HOLE DIMENSIONS ADDED TO FLUSH FLAT PANEL VIEW. NOTES 4 AND 5 AMENDED (SHT 1). VIEW SHOWING PANEL FIXINGS UPDATED. #1281 **VSL-16xW INTERCOM STATION INSTALLATION DETAILS** LFB 2016-09-13 N/A VSL-16xW-INS.dwg N.T.S. VSL-16xW-INS

