



INSTALLATION OF VSL-x6x INTERCOMS USING PWB-4 (51812)
PLASTERBOARD WALL MOUNTING BRACKET



WALL BRACKET
(FOR PLASTERBOARD
WALL MOUNTING)

MODEL : PWB-4
PART No : 51812



INSTALLATION INSTRUCTIONS

1. USE PLASTERBOARD BRACKET AS MARKING GUIDE FOR WALL CUTOUT SIZE AND 6 FIXING HOLE POSITIONS IN WALL.

2. BEND THE UPPER TAB IN BRACKET AS SHOWN. **(A)**


3. BEND THE LOWER TAB IN BRACKET AS SHOWN. **(B)**


4. INSERT WALL BRACKET THROUGH CUTOUT AT ANGLE SHOWN. **(C)**
ROTATE BRACKET TO VERTICAL POSITION UP AGAINST BACK OF PLASTER BOARD WALL.

5. HOOK LOWER TAB OVER EDGE OF CUTOUT AS SHOWN. **(D)**

6. FOLD UPPER TAB OVER CUTOUT EDGE AS SHOWN. **(E)**

7. FIT UNIT WITH 6 M4 x 30 mm S/S SECURITY SCREWS. **(F)**





Future Proof Communications
288 Montague Rd., West Epping, 4177, Australia
www.jacques.com.au Fax: info@jacques.com.au

(C) Copyright Jacques Technologies Pty Ltd. All rights reserved.
288 Montague Rd., West Epping, 4177, Australia
www.jacques.com.au Fax: info@jacques.com.au

PWB-4 INSTALLATION DETAILS

DRAWN:	DATE:	ADAPTED FROM:	FILENAME:
LFB	2015-08-03	N/A	51812-INS.dwg
CHECKED:	DATE:	SCALE:	SHEET:
		N.T.S.	1 of 1
APPROVED:	DATE:	DWG NO:	REV:
		51812-INS	0