

## JACQUES TO CNL HIGH LEVEL INTERFACE

PRODUCT CODE SOF116-CNL

### OVERVIEW

The Jacques to CNL High Level Interface (HLI) allows the Jacques Integrated Communication System (650 series) to integrate into the CNL IPSecurityCenter™. This integration allows organisations to create a Common Operating Picture (COP) of their entire infrastructure for all stakeholders through the integration of all security assets. It allows users to maximise their existing investment in equipment and seamlessly deploy new technologies, creating significant cost savings through efficient use of all security resources. Significantly, it allows intelligence from these systems, whether audio, video or data to be fully connected to an organisations infrastructure to create real business value.

### FUNCTIONALITY

The below listed intercom functionality is available at the CNL IPSecurityCenter™

|                                    |  |
|------------------------------------|--|
| <b>Intercom Functions</b>          | <ul style="list-style-type: none"> <li>Make intercom calls</li> <li>Receive intercom calls</li> <li>Terminate intercom calls</li> <li>Forward intercom calls</li> <li>Place intercom on hold</li> <li>Pending intercom call notification (call queue)</li> <li>Adjust intercom call volume</li> <li>Control music streaming function of intercom</li> <li>Covertly monitor intercoms</li> <li>Remote or isolate intercoms</li> </ul>   |
| <b>PA Functions</b>                | <ul style="list-style-type: none"> <li>Select PA zones for broadcast</li> <li>Make/terminate PA calls</li> <li>Group PA zone calling</li> <li>Soft button intercom Push-to-Talk</li> </ul>   |
| <b>Relay &amp; Events</b>          | <ul style="list-style-type: none"> <li>Trigger alarm - intercom event</li> <li>Trigger alarm - activate intercom associated 3rd party CCTV</li> <li>Trigger alarm - activate intercom associated 3rd party CCTV along with audio from intercom</li> <li>View CCTV stream from Jacques Video Intercom device</li> <li>View CCTV stream along with audio from Jacques Video Intercom device</li> <li>Activate door/gate relay</li> </ul> |
| <b>Diagnostics &amp; Reporting</b> | <ul style="list-style-type: none"> <li>System controller connection status</li> <li>Monitor endpoint status change (online/offline/alarm)</li> <li>Site specific information distribution</li> <li>Events logging</li> <li>Alarms and alerts logging</li> </ul>  |
| <b>Recording</b>                   | <ul style="list-style-type: none"> <li>Records intercom associated 3rd party CCTV</li> <li>Records intercom associated 3rd party CCTV in conjunction with intercom audio</li> <li>Export recordings</li> </ul>   |
| <b>Graphical Maps</b>              | <ul style="list-style-type: none"> <li>Display Jacques Intercoms on Graphical Maps</li> <li>Dynamically change the display of Jacques intercoms based on their current status</li> </ul>   |

#### FUNCTIONALITY

---

##### **Graphical Maps**

Control Jacques intercoms from Graphical Maps  
Automatically zoom in on intercoms based on alarm trigger events

---

##### **Alarm Management**

Automatically control intercoms based on alarms received from 3rd party system  
Automatically control doors, areas, relays etc. based on events from Jacques system  
Automatically control compatible 3rd party systems (e.g. CCTV) based on events from Jacques system

---

#### VERSIONS

IPSecurityCenter™ V5.3 and above

Jacques IP Communication System V7.46 and above

#### DEVELOPER

CNL Software